



# FOX REAR SHOCKS INSTALLATION GUIDE MERCEDES SPRINTER 2500



**Lift vehicle and support vehicle with jack stands using trailer hitch or factory jack points. Remove wheels.**

**Remove old shocks. Start with lower bolt. Discard shocks. Save factory bolts, you'll reuse them.**



**Install new shocks. Start with top bolt. Included washer goes between the shock & frame.**

**Upper Shock Bolt Torque Specs: 110 LB**

**(Note: clean factory bolts & apply loc-tite before installing)**



**Use a jack to manipulate axle up or down to line up holes for lower shock bolt. Install lower shock bolt.**

**Lower Shock Bolt Torque Specs: 75 LB**

**Reinstall wheels & lower vehicle.**