

INSTALLATION GUIDE



**AGILE
OFFROAD**

SMARTER THAN DIRT®

GRENADIER SPARE TIRE ADAPTER KIT

GENERAL INFORMATION

The AO Ineos Grenadier Spare Tire Adapter Kit is designed to be installed on the '24 and newer vehicles. This adapter kit allows for the installation of a larger spare tire while still maintaining the ability to open the rear 30/70 split doors.

****Read the instructions completely before starting the installation process.****

PARTS INCLUDED

Part # AO-E6G-1:

- 1 X Spare Tire Billet Adapter
- 1 X Foam Gasket
- 3 X Splined Acorn Lug Nuts
- 3 X 14mm x 1.5 Flange Nuts
- 1 X Splined Lug Socket

TOOLS NEEDED

- Flat Screw Driver
- 10mm Socket/Wrench
- 19mm Socket/Wrench
- 21mm Socket Wrench
- Torque Wrench (ft lbs)





1. Park vehicle on flat ground.



2. Use a screw driver to remove the wheel cover center bolt cover.



3. Use a 10mm (or appropriate type) socket/wrench to remove the wheel cover center bolt then remove cover.



4. Use a 21mm socket/wrench to remove the wheel lug bolts. The factory supplied lug key will be required to remove the locking lug nut.



5. Remove the wheel cover bracket and then remove the spare wheel/tire.



6. Clean the factory spare wheel/tire bracket.



7. Install the supplied gasket.



8. Use the supplied 14mm flange nuts to install the AO Tire Adapter.



9. Torque the 14mm flange bolts to 80 ft lbs.



10. Use the supplied splined lug nuts and key to install your spare tire/wheel show face out. Torque wheel lug nuts to 80 ft lbs.