

# Safari Molle Installation instructions

Parts for each:

- 1: Safari Molle panel.
- 2: Bracket marked “O”. (Outside)
- 3: Bracket marked “F”. (Front)
- 4 Bracket marked “I”. (Inside)
- 5: Three attachment screws.

## **Installation:**

While sitting in the vehicle insert the bracket between the rubber gasket and the frame of the Safari Windows. **The Bracket with the marked “O”** will be placed on the door window side of the vehicle.

**The Bracket marked “F”** will be placed at the front of the window frame. (Closest to the windshield.)

**The Bracket marked “I”** will be placed opposite the “O” bracket or towards the center or Inside of the vehicle.

**Install the panel using the supplied screws and starting with the “F” bracket** and adjust the other two brackets to match the holes in the panel. Tighten and repeat on the other Safari Window.