



INSTALLATION GUIDE

Auxiliary Cooling Support Brackets for Grenadier by Agile Offroad

G21-1002



INSTALLATION GUIDE



Auxiliary Cooling Support Brackets for Grenadier by Agile Offroad



The factory auxiliary cooling brackets on the INEOS Grenadier are not designed to handle the full weight of the auxiliary coolers when pushed hard off-road. Over time, this can lead to stress and eventual failure. Agile Offroad's powder-coated steel support brackets solve this by adding an extra mounting point, reinforcing the system, and providing the strength needed for heavier use in demanding conditions.

SKU

G21-1002

PARTS INCLUDED

Right Side Cooler Bracket

Left Side Cooler Bracket

TOOL NEEDED

Clip Removal Tool

T30 Torx Bit

T45 Torx Bit

13mm Open Wrench

16mm Socket w/3" Extension

INSTALLATION TIME

30-45 Minutes





INSTALLATION GUIDE



• Use a clip removal tool to remove the two upper panel clips. Then use a T30 Torx bit to remove the two outer panel screws.



Z. Use a T30 Torx bit to remove the three lower panel screws then completely remove panel.



3. Use a 13mm wrench to remove the tube bracket mount from the lower cooler bracket. Then use a T45 Torx bit to remove the tube bracket screw from the chassis. Completely remove tube bracket.



4. Use a 16mm socket w/3" extension to remove the two upper skid plate bracket bolts.



5. Install the new AO Cooler Bracket using the factory hardware. Torque the lower bracket bolt and the lower cooler nut to 18lb ft. Torque the upper bracket bolts to 31 ft lbs.









Exterior



Suspension Air Locker &



Drivetrain



Steering & Brakes



Air Compressors



Armor & Protection



Bumpers



Lighting



Wheels & Tires



Storage & Racks



Water & Fuel Tanks



Winches & Recovery



Replacement Parts & Accessories



Electrical



Tools



